

## Typ/Type 9170/\*1



Schaltverstärker Switching Repeater



## Inhaltsverzeichnis

1 Sicherheitshinweise	3 4 5 5 6 7 7 7 7 8 8 9 10 10
1 Safety instructions	. 12 . 13 . 13 . 14 . 14 . 15 . 16 . 16 . 17 . 17 . 18 . 19 . 19
EG-Konformitätserklärung / EC-Declaration of Conformity  Certification drawing – FM Type 9170/*1  Certification drawing – CSA Type 9170/*1	. 22

#### 1 Sicherheitshinweise

In diesem Kapitel sind die wichtigsten Sicherheitsmaßnahmen zusammengefasst. Es ergänzt die entsprechenden Vorschriften, zu deren Studium das verantwortliche Personal verpflichtet ist.

Bei Arbeiten in explosionsgefährdeten Bereichen hängt die Sicherheit von Personen und Anlagen von der Einhaltung aller relevanten Sicherheitsvorschriften ab. Das Montage- und Wartungspersonal trägt deshalb eine besondere Verantwortung. Die Voraussetzung dafür ist die genaue Kenntnis der geltenden Vorschriften und Bestimmungen.

#### Bei Errichtung und Betrieb ist Folgendes zu beachten:

- Es gelten die nationalen Montage- und Errichtungsvorschriften (z.B. EN 60079-14)
- Der Schaltverstärker ist außerhalb explosionsgefährdeter Bereiche zu installieren.
- Die Schaltverstärker Typen 9170/\*1-\*0-1\*; 9170/\*1-\*1-1\* und 9170/\*1-\*4-1\* sind auch für den Betrieb in explosionsgefährdeten Bereichen der Zone 2 und Zone 22 zugelassen.
- Bei Einsatz in Zone 2 sind die Schaltverstärker in ein Gehäuse einzubauen, das den Anforderungen der EN 60079-15 genügt.
- Bei Einsatz in Zone 22 sind die Schaltverstärker in ein Gehäuse einzubauen, das den Anforderungen der EN 61241-1 genügt.
- Bei Einsatz in Zone 2 und Zone 22 dürfen an die eigensicheren Eingangsstromkreise auch eigensichere Geräte der Zonen 1, 0, 21 und 20 angeschlossen werden.
- Der Schaltverstärker darf nur an Geräte angeschlossen werden, in denen keine höheren Spannungen als AC 253 V (50 Hz) auftreten können.
- Die sicherheitstechnischen Werte der / des angeschlossenen Feldgeräte/s müssen mit den Angaben des Datenblattes bzw. der EG-Baumusterprüfbescheinigung übereinstimmen.
- Bei Zusammenschaltungen mehrerer aktiver Betriebsmittel in einem eigensicheren Stromkreis können sich andere sicherheitstechnische Werte ergeben. Hierbei kann die Eigensicherheit gefährdet werden!
- Die nationalen Sicherheits- und Unfallverhütungsvorschriften
- Die allgemein anerkannten Regeln der Technik
- Die Sicherheitshinweise dieser Betriebsanleitung
- Beschädigungen können den Explosionsschutz aufheben.

Verwenden Sie das Gerät **bestimmungsgemäß**, nur für den zugelassenen Einsatzzweck (siehe "Funktion").

Fehlerhafter oder unzulässiger Einsatz sowie das Nichtbeachten der Hinweise dieser Betriebsanleitung schließen eine Gewährleistung unsererseits aus. Umbauten und Veränderungen am Gerät, die den Explosionsschutz beeinträchtigen, sind nicht gestattet.

Das Gerät darf nur in unbeschädigtem, trockenem und sauberem Zustand eingebaut und betrieben werden.

#### 2 Normenkonformität

Bitte entnehmen sie die Normenkonformität der EG-Konformitätserklärung im Anhang dieses Dokumentes.

Die aktuelle EG-Baumusterprüfbescheinigung können Sie im Internet unter <u>www.stahl.de</u> herunterladen.

#### 3 Funktion

Die Schaltverstärker werden zum eigensicheren Betrieb von z.B. Kontakten, Initiatoren nach EN 60947-5-6 (NAMUR), Optokopplerausgängen usw. eingesetzt. Für unterschiedliche Anforderungen stehen Ausgangsvarianten mit Signalrelais, Leistungsrelais oder Optokoppler zur Verfügung.

#### 4 Kennzeichnung und technische Daten

Hersteller Typbezeichnung CE-Kennzeichnung ATEX Kennzeichnung Explosionsschutz	R. STAHL 9170/*1-1*-** <b>C C</b> <sub>0158</sub> 9170/*1-*-2* 9170/*1-*2-1* 9170/*1-*3-1*	9170/*1-*0-1* 9170/*1-*1-1* 9170/*1-*4-1*
und Prüfstelle und Bescheinigungsnummer IECEx Kennzeichnung Explosionsschutz	( )   (1) G [Ex ia]     C ( )   (1) D [Ex ia]     C DMT 02 ATEX E 195	
Prüfstelle und Bescheinigungsnummer max. Umgebungstemperaturbereich	[Ex ia] IIC [Ex ia] IIIC IECEx BVS 09.0041) -20 °C + 70 °C	Ex nAc nCc [ia] IIC T4 [Ex ia] IIIC (
Sicherheitstechnische Daten max. Spannung, U <sub>o</sub> max. Strom, I <sub>o</sub> max. Leistung, P <sub>o</sub> innere Kapazität, C <sub>i</sub> innere Induktivität, L <sub>i</sub> max. anschließbare Kapazität, C <sub>o</sub> IIC / IIB max. anschließbare Induktivität, L <sub>o</sub> IIC / IIB Isolationsspannung U <sub>m</sub>	(Siehe Kapitel 5.1) 1 Kanal 9,6 V 10 mA 24 mW 2,42 nF vernachlässigbar 3,6 µF / 26 µF 350 mH / 1000 mH 253 V	2 Kanäle parallel 9,6 V 20 mA 48 mW 4,84 nF vernachlässigbar 3,6 μF / 26 μF 90 mH / 340 mH 253 V

Weitere Angaben und Wertekombinationen siehe EG-Baumusterprüfbescheinigung.

```
Technische Daten (Auszug aus dem
Datenblatt)
Hilfsenergie
 Nennspannung U<sub>N</sub>
    DC-Versorgung (Typen 9170/*1-**-11)
                                               24 V DC
    AC-Versorgung (Typen 9170/*1-**-21)
                                               120 / 230 V AC
 Nennstrom (bei U<sub>N</sub>) DC-/AC-Versorgung
                                               50 mA / 13 mA
 Leistungsaufnahme (bei U<sub>N</sub>)
                                               0,9 W / 2 VA
                                               gem. EN 60947-5-6
Ex i Eingang
Ausgang (s.a. Betrieb und Betriebszustände)
 Signalrelais (9170/*1-*0-*1; 9170/*1-11-*1)
                                               max. 125 V AC/DC / 1 A
 Leistungsrelais (9170/*1-12-*1;
                                               max. 250 V AC / 4 A; 250 V DC / 2 A
 9170/*1-13-*1)
                                               35 V DC / 50 mA
 Elektronikausgang (9170/*1-14-*1)
Umgebungsbedingungen
                                               -20...+70 °C
max. Betriebstemperatur
 Lagertemperatur
                                               -40...+80 °C
 relative Feuchte (keine Betauung)
                                               < 95 %
```

Weitere technische Daten sind dem aktuellen Datenblatt zu entnehmen.



Bei anderen vom Standard abweichenden Betriebsbedingungen nehmen Sie bitte Rücksprache mit dem Hersteller.

## 5 Projektierung

#### 5.1 Maximal zulässige Umgebungstemperaturen

Die Geräte der Reihe ISpac sind über einen weiten Temperaturbereich einsetzbar. Je nach Geräteausführung und Einbaubedingung ergeben sich unterschiedliche, maximal zulässige Umgebungstemperaturen.

	Belüftung:		Ohne Umluft				
	Installation:	Einzelgerät	DIN-Schiene		ät DIN-Schiene pac-Träger		räger
	Einbaulage:	beliebig	vertikal	horizontal	vertikal	horizontal	
Kanäle	Тур:						
	9170/11-11-1* 9170/11-12-1*		65 °C	65 °C	60 °C	65 °C	
1	9170/11-14-1*	70 °C	70 °C	70 °C	65 °C	70 °C	
	9170/11-11-2* 9170/11-12-2*		65 °C	70 °C			
	9170/21-*0-1* 9170/21-11-1* 9170/21-12-1*		55 °C	60 °C	50 °C	55 °C	
2	9170/21-14-1*	70 °C	65 °C	65 °C	60 °C	65 °C	
	9170/21-10-2* 9170/21-11-2* 9170/21-12-2*		55 °C	60 °C			
	Belüftung:		Mit Umluft				
	Installation:	Einzelgerät	DIN-S	chiene	pac-T	räger	
	Einbaulage:	beliebig	vertikal	horizontal	vertikal	horizontal	
Kanäle	Тур:						
	9170/11-11-1* 9170/11-12-1*		70 °C	70 °C	70 °C	70 °C	
1	9170/11-14-1*	70 °C	70 °C	70 °C	70 °C	70 °C	
	9170/11-11-2* 9170/11-12-2*		70 °C	70 °C			
	9170/21-*0-1* 9170/21-11-1* 9170/21-12-1*		65 °C	65 °C	60 °C	65 °C	
2	9170/21-14-1*	70 °C	70 °C	70 °C	65 °C	65 °C	
	9170/21-10-2* 9170/21-11-2* 9170/21-12-2*		65 °C	65 °C			

#### 5.2 Verlustleistung

In den Datenblättern wird die max. Verlustleistung im Nennbetrieb angegeben. Da in der Praxis nicht alle Geräte gleichzeitig unter Volllast betrieben werden, erfolgt die Projektierung üblicherweise mit einer durchschnittlichen Verlustleistung von 70 %. (P<sub>70%</sub>).

Тур	Kanäle	max. Verlustleistung	70 % Verlustleistung
9170/11-11*	1	0,7 W	0,5 W
9170/21-**-1*	2	1,2 W	0,8 W
9170/11-14-1*	1	0,6 W	0,4 W
9170/21-14-1*	2	0,7 W	0,5 W

Betriebsanleitung deutsch

#### 5.3 Projektierung der Verlustleistung in Schaltschränken

Beim Einbau von Geräten innerhalb von Schaltschränken wird der freie Luftstrom begrenzt und die Temperatur steigt. Um die Temperaturerhöhung zu minimieren, ist es wichtig, die Verlustleistung sowie die produzierte Wärme innerhalb des Schrankes zu optimieren.

#### a) Natürliche Konvektion in geschlossenen Schränken

- Anwendung: bei geringer Verlustleistung und wenn das System in einer staubigen oder rauen Umgebung installiert ist
- Berechnung der maximal zulässigen Verlustleistung:

#### $P_{max} = \Delta t * S * K$

P<sub>max</sub> [W] max. zulässige Verlustleistung im Schaltschrank

Δt [°C] max. zulässige Temperaturerhöhung

 $S [m^2]$  freie, wärme-emittierende Oberfläche des Schaltschrankes  $K [(W/m^{2^*}C)]$  thermischer Leitfähigkeitskoeffizient (lackierter Stahl: K = 5,5)

Der errechnete Wert  $P_{max}$  muss kleiner als die Summe der durchschnittlichen Verlustleistungen (70 % der max. Verlustleistung) der eingebauten Geräte sein:  $P_{max} < \sum P_{70\%}$ 

#### b) Natürliche Konvektion in offenen Schränken

• Funktion: die Wärme wird mittels kühler Luftströme zwischen den Geräten verdrängt

- · Voraussetzungen:
  - Luftein und Auslassöffnungen an den unteren und oberen Enden des Schrankes
  - der Weg des Luftstroms muss frei von Hindernissen gehalten werden
- <u>Ergebnis:</u> Je nach Ausführung kann die **doppelte** zulässige Verlustleistung wie unter a) erreicht werden.

#### c) Erzwungene Belüftung mit Wärmetauscher in geschlossenen Schränken

- Anwendung: wenn entweder die Umgebung oder die hohe Verlustleistung keine natürliche Konvektion erlauben
- <u>Funktion</u>: ein Wärmetauscher mit Lüfter saugt Luft in den Schrank und drückt sie in die Wärmetauscherplatten, die durch einen zweiten Lüfter mit Umgebungsluft gekühlt werden
- <u>Ergebnis</u>: Je nach Ausführung kann die 5- bis 6-fache zulässige Verlustleistung wie unter a) erreicht werden.

#### d) Erzwungene Belüftung in offenen Schränken

- <u>Funktion</u>: Ein oder mehrere Lüfter erzeugen einen Luftstrom von der unteren Schranköffnung an den Geräten vorbei durch die obere Schranköffnung hinaus.
- Berechnung des notwendigen Luftstroms:

#### $Q = (3,1 * P_{70\%}) / \Delta t$

Q [m³/h] notwendiger Luftstrom

P<sub>70%</sub> [W] entstehende Verlustleistung (70 % der max. Verlustleistung)


 $\Delta t$  [°C] zulässige Temperaturerhöhung im Schaltschrank

#### e) Klimaanlage

- Anwendung: bei heißem Klima eine Schranktemperatur gleich groß oder geringer als die Umgebungstemperatur ist erreichbar.
- <u>Funktion</u>: Nutzung eines spezifisches Kältemaschinen-Systems oder des existierenden Klimasystems für die Schrankkühlung.

## 6 Anordnung und Montage

#### 6.1 Maßzeichnung



	Maß X
Schraubklemmen	108 mm
Federzugklemmen	128 mm

#### 6.2 Installation

Der Schaltverstärker ist außerhalb explosionsgefährdeter Bereiche zu installieren. Die Schaltverstärker Typen 9170/\*1-\*0-1\*; 9170/\*1-\*1-1\* und 9170/\*1-\*4-1\* sind auch für den Betrieb in explosionsgefährdeten Bereichen der Zone 2 und Zone 22 zugelassen. Die Geräte sind hierbei in ein Gehäuse einzubauen, das den Anforderungen der EN 60079-15 bzw. EN 61241-1 genügt (z.B. Gehäuse 8146 der R. STAHL Schaltgeräte GmbH).

#### 6.3 Montage und Demontage

#### a) Abziehbare Klemmen

Alle Geräte sind mit abziehbaren Klemmen versehen. Zum Abziehen die Klemmen mit z.B. einem Schraubendreher wie im Bild dargestellt lösen.



Geräte wie im Foto dargestellt ansetzen und auf die DIN-Schiene aufschwenken. Dabei nicht verkanten. Zur Demontage den Fußriegel mit einem Schraubendreher etwas herausziehen und das Modul entnehmen.



Geräte wie im Foto oben dargestellt ansetzen und auf die DIN-Schiene mit dem installierten pac-Bus aufschwenken.

Dabei nicht verkanten.

<u>Hinweis</u>: um eine Verpolung bei der Installation zu verhindern, sind die pac-Bus-Elemente mit einer Codierleiste (siehe Foto) und die Module mit dem entsprechenden Codierschlitz versehen.

Demontage wie unter b) beschrieben.







#### d) Montage im pac-Träger

Die schwarzen und grünen Klemmen müssen vor der Installation entfernt werden. Bei einkanaligen Geräten muss zusätzlich die Abdeckung der Stiftleisten der zweiten Ebene entfernt werden (mit Schraubendreher an der unteren Kante aushebeln).


Die ISpac Module wie unter a) und b) beschrieben ansetzen und in den pac-Träger vollständig einschwenken.

Den roten Rasthebel mit leichtem Druck schließen. Der Rasthebel muss vollständig eingerastet sein.




Zur Demontage den Rastmechanismus mit einem Schraubendreher wie im Bild dargestellt öffnen. Das Modul wird aus dem Steckplatz geschoben und kann entnommen werden.

#### Inbetriebnahme 7



9170/	/21-11-**	/11-11-**	/21-*0-** /21-*2-**	/11-12-**	/21-14-**	/11-14-**
Kanal 2	06 05 04		\$ 06 05 04		→ 06 05	
Kanal 1	\$\frac{03}{02}\$	06 05 04 03 02 01	©3 02 01	©3 02 01	⇒ C2 01	⇒ 02 01

Besondere Ausgangsbeschaltung der Typen 9170/11-14-12 LFT, 9170/11-14-12-C1515 LFT, 9170/21-14-12 LFT, und 9170/21-14-12-C1515 LFT:




Diese Beschaltung erlaubt dem nachgeschalteten Automatisierungssystem, die durch den Schaltverstärker erkannten Leitungsfehler im eigensicheren Feldstromkreis (Kurzschluss oder Leitungsbruch), über den Ausgang des Schaltverstärkers direkt zu erkennen. Dies wird durch die zusätzliche Widerstandsbeschaltung und einem zusätzlichen Öffner im Ausgang ermöglicht. Dem Automatisierungssystem wird der erkannte Leitungsfehler – egal ob Kurzschluss oder Leitungsbruch - als Drahtbruch weitergemeldet. Die Typen 9170/11-14-12-C1515 LFT und 9170/21-14-12-C1515 LFT dürfen nur an Yokogawa ProSafe angeschlossen werden.

#### 7.2 Projektierung

a) Beschaltung zur Leitungsfehlererkennung bei spannungsfreien Kontakten am Eingang:

Drahtbrucherkennung: 10 k $\Omega$  parallel Kurzschlusserkennung: 1 k $\Omega$  in Reihe

Die Beschaltung ist in unmittelbarer Nähe des Kontaktes vorzunehmen.




b) Beschaltung bei Induktiven Lasten am Ausgang:



Induktive Lasten müssen mit einer Freilaufdiode beschaltet werden.

Von einer Beschaltung mittels Varistor raten wir ab.



#### 7.3 Einstellungen

	Leitungsfehlere	erkennung LF	Wirkungsrichtung invertiert INV		
	deaktiviert *) aktiviert		Aus *)	Ein	
Kanal 1	OFF ON  LF1  1 INV1	OFF ON  LF1  INV1	OFF ON LF1 1 INV1	OFF ON LF1 INV1	
Kanal 2	2 LF2 INV2	2 LF2 INV2	2 LF2 INV2	2 LF2 INV2	

<sup>\*)</sup> Standardeinstellung bei Auslieferung

Die Änderung der DIP-Schalter-Einstellungen ist im Betrieb auch in der Zone 2 und bei angeschlossenen, eigensicheren Eingangssignalen zulässig.

Betriebsanleitung deutsch

#### 8 Betrieb und Betriebszustände

		Zustand des Ausgangs bei "Wirkungsrichtung invertiert" (siehe 7.3)				
Eingang	Signal	Aus Ein				
Leitungsfehlererkennung	Leitungsfehlererkennung LF = deaktiviert					
Initiator hochohmig / Kontakt geöffnet / Drahtbruch	I <sub>E</sub> ≤ 1,2 mA	Relais nicht erregt / Elektronikausgang sperrt	Relais erregt / Elektronikausgang leitet			
Initiator niederohmig / Kontakt geschlossen / Kurzschluss	I <sub>E</sub> ≥ 2,1 mA	Relais erregt / Elektronikausgang leitet	Relais nicht erregt / Elektronikausgang sperrt			
Leitungsfehlererkennung	LF = aktiviert					
Drahtbruch	I <sub>E</sub> ≤ 0,050,35mA	Relais nicht erregt / Elektronikausgang sperrt	Relais nicht erregt / Elektronikausgang sperrt			
Initiator hochohmig / Kontakt geöffnet	I <sub>E</sub> = 0,351,2 mA	Relais nicht erregt / Elektronikausgang sperrt	Relais erregt / Elektronikausgang leitet			
Initiator niederohmig /Kontakt geschlossen	I <sub>E</sub> = 2,15 mA	Relais erregt / Elektronikausgang leitet	Relais nicht erregt / Elektronikausgang sperrt			
Kurzschluss	R <sub>E</sub> < 100360 Ω	Relais nicht erregt / Elektronikausgang sperrt	Relais nicht erregt / Elektronikausgang sperrt			

Ausnahme sind die Typen 9170/11-14-12 LFT, 9170/11-14-12-C1515 LFT, 9170/21-14-12 LFT, und 9170/21-14-12-C1515 LFT (siehe Beschreibung Kapitel 7.1)

## 9 Reparatur und Instandhaltung

Es wird empfohlen, Reparaturen an unseren Geräten ausschließlich durch R. STAHL durchführen zu lassen. In Ausnahmefällen kann die Reparatur auch durch eine andere, zugelassene Stelle erfolgen.

Die Geräte sind wartungsfrei.

#### Fehlersuchplan:

Fehlererkennung	Fehlerursache	Fehlerbehebung
LED "PWR" erloschen	- Hilfsenergie ausgefallen	Hilfsenergieversorgung kontrollieren.
	- Gerätesicherung defekt	Bei defekter Sicherung das Gerät zur Reparatur
		geben.
	- Hilfsenergieversorgung verpolt	Korrekte Polung herstellen
LED "LF" Leitungsfehler	- Schaltelement nicht korrekt	Korrekte Verdrahtung des Schaltelementes
leuchtet ständig	angeschlossen	sicherstellen.
	- Schaltelement funktioniert nicht	Spannungsfreie Kontakte entsprechend Punkt
	entsprechend NAMUR	7.2 mit zusätzlichen Widerständen beschalten.
Keine Änderung des	- Vertauschung der abziehbaren Klemmen	Stecken sie die abziehbaren Klemmen an den
Schaltzustandes am		dafür vorgesehenen Anschluss im Gerät.
Ausgang trotz		
Aufleuchten der gelben		
LED "OUT"		
Hohe Schaltfrequenzen	<ul> <li>Die Version des Schaltverstärkers mit</li> </ul>	Durch externe Beschaltung mit einem
werden nicht	elektronischem Ausgang ist optimiert für	Widerstand zur Versorgungsspannung (z.B.
übertragen	den Einsatz mit aktiven E/A Karten. Beim	+5V) wird der High Level erzeugt.
	Einsatz mit passiven Eingängen fehlt das	
	Potential zur Erzeugung vom High Level.	

deutsch Betriebsanleitung

#### Selbsttest:

Um einige wichtige Funktionen des Geräts zu überprüfen, können Sie die folgenden Testschritte durchführen. Sollte das Gerät bereits verdrahtet sein, so trennen Sie bitte die abziehbaren Klemmen vom Gerät (siehe Punkt 6.3).

- Stellen Sie sicher, dass das Gerät mit Hilfsenergie versorgt wird. (mittels pac Bus oder direkt über die Klemmen 7 und 9).
- Deaktivieren Sie die Leitungsfehlererkennung mit Hilfe der DIP Schalter auf der Frontseite des Gerätes (siehe Punkt 7.3).
- Stellen sie eine leitende Verbindung zwischen Klemme 10/11 (f
  ür zweikanalige Ger
  äte zus
  ätzlich Klemme 14/15) her.
- Das Gerät sollte bei korrekter Funktion mit dem Aufleuchten der gelben LED "OUT" reagieren. Das Auftrennen der leitenden Verbindung sollte zum Erlöschen der LED führen. -> Das Gerät reagiert grundsätzlich auf Eingangssignale.
- Aktivieren Sie die Leitungsfehlererkennung.
- Verbinden und Auftrennen der Verbindung an den Klemmen 10/11 und 14/15 führt zum Aufleuchten der roten LED "LF" -> Die Leitungsfehlererkennung spricht für Kurzschluss und Drahtbruch an.

Führen die beschriebenen Vorgehensweisen nicht zum gewünschten Erfolg, wenden Sie sich bitte an unsere nächste Vertriebsniederlassung. Zur schnellen Bearbeitung benötigt diese von Ihnen folgende Angaben:

- Typ und Seriennummer
- Kaufdaten
- Fehlerbeschreibung
- Einsatzzweck (insbesondere Eingangs-/Ausgangsbeschaltung)

#### 10 Zubehör und Ersatzteile

Verwenden Sie nur Original-Ersatzteile der Fa. R. STAHL Schaltgeräte GmbH.

#### 1 Safety instructions

The most important safety instructions are summarised in this chapter. It is intended to supplement the relevant regulations which must be studied by the personnel responsible.

When working in hazardous areas, the safety of personnel and plant depends on complying with all relevant safety regulations. Assembly and maintenance staff working on installations therefore have a particular responsibility. The precondition for this is an accurate knowledge of the applicable regulations and provisions.

#### When installing and operating the device, the following are to be observed:

- The national installation and assembly regulations (e.g. EN 60079-14) apply.
- The switching repeater is to be installed outside of hazardous areas.
- Type 9170/\*1-\*0-1\*; 9170/\*1-\*1-1\* and 9170/\*1-\*4-1\* switching repeaters are also approved for operation in Zone 2 and Zone 22 hazardous areas.
- If installed in Zone 2, the switching repeaters are is to be fitted into an enclosure which meets the requirements of EN 60079-15.
- If installed in Zone 22, the switching repeaters are is to be fitted into an enclosure which meets the requirements of EN 61241-1.
- If installed in Zone 2 and Zone 22, devices connected to the intrinsically safe input circuits of Zone 1, 0, 21 and 20 may be connected.
- The switching repeaters may only be connected to devices which will not be subjected to voltages higher than AC 253 V (50 Hz).
- The safe maximum values of the connected field device(s) must correspond to the values of the data sheet or the EC-type examination certificate.
- Interconnecting several active devices in an intrinsic safety circuit may result in other safe maximum values. This could endanger the intrinsic safety!
- National safety and accident prevention regulations.
- Generally recognised technical regulations.
- Safety guidelines in these operating instructions.
- Any damage can compromise and even neutralise the explosion protection.

Use the device in accordance with the regulations and for its intended purpose only (see "Function").

Incorrect or impermissible use or non-compliance with these instructions invalidates our warranty provision.

No changes to the devices or components impairing their explosion protection are permitted.

Further, the device may only be fitted if it is undamaged, dry and clean.

## 2 Conformity to standards

The information about the conformity to standards can be found in the manufacturer's declaration of conformity in the appendix of this document.

The current EC-Type Examination Certificate can be downloaded from the Internet <a href="https://www.stahl-ex.com">www.stahl-ex.com</a> .

#### 3 Function

Switching repeaters are used for intrinsically safe operation of contacts, proximity switches as defined by EN 60947-5-6 (NAMUR), optocoupler outputs, etc.

Output variants equipped with signal relays, power relays or optocouplers have been provided to meet varying requirements.

#### 4 Marking and technical data

R. STAHL	
9170/*1-1*-**	
C <sub>0158</sub>	
9170/*1-* *-2*	9170/*1-*0-1*
9170/*1-*2-1*	9170/*1-*1-1*
9170/*1-*3-1*	9170/*1-*4-1*
EII (1) G [Ex ia] IIC	EII 3 (1) G Ex nAc nCc [ia] IIC T4
Ell (1) D [Ex ia] IIIC	EII (1) D [Ex ia] IIIC
DMT 02 ATEX E 195	X
[Ex ia] IIC	Ex nAc nCc [ia] IIC T4
[Ex ia] IIIC	[Ex ia] IIIC
pending	
-20 °C + 70 °C	
(See chapter 5.1)	
1 channel	2 channels parallel
9.6 V	9.6 V
10 mA	20 mA
24 mW	48 mW
2.42 nF	4.84 nF
negligible	negligible
3.6 µF / 26 µF	3.6 μF / 26 μF
350 mH / 1000 mH	90 mH / 340 mH
253 V	253 V
	9170/*1-1*-**  C <sub>0158</sub> 9170/*1-**-2* 9170/*1-**-2-1* 9170/*1-*3-1* Ell (1) G [Ex ia] IIC Ell (1) D [Ex ia] IIIC DMT 02 ATEX E 195 [Ex ia] IIC [Ex ia] IIIC pending -20 °C + 70 °C (See chapter 5.1) 1 channel 9.6 V 10 mA 24 mW 2.42 nF negligible 3.6 µF / 26 µF 350 mH / 1000 mH

See EC-type examination certificate for further information and value combinations.

```
Technical data (excerpted from the data
sheet)
Power supply
 Nominal voltage U<sub>N</sub>
    DC power supply (Types 9170/*1-**-11)
                                                24 V DC
    AC power supply (Types 9170/*1-**-21)
                                                120 / 230 V AC
 Nominal current (for U<sub>N</sub>) DC/AC power
                                                50 mA / 13 mA
supply
 Power consumption (for U<sub>N</sub>)
                                                0.9 W / 2 VA
I.S. Input
                                                in acc. with EN 60 947-5-6
Output (see Operation and operational
states)
 Signal relay (9170/*1-*0-*1; 9170/*1-11-*1)
                                                max. 125 V AC/DC / 1 A
 Power relay (9170/*1-12-*1; 9170/*1-13-*1)
                                                max. 250 V AC / 4 A; 250 V DC / 2 A
 Electronic output (9170/*1-14-*1)
                                                35 V DC / 50 mA
Ambient conditions
                                                -20...+70 °C
 Max. operating temperature
                                                -40...+80 °C
 Storage temperature
                                                < 95 %
 Relative humidity (no condensation)
```

Additional technical data can be found in the current data sheet.



Please consult with the manufacturer before operating under conditions which deviate from the standard operating conditions.

## 5 Engineering

#### 5.1 Max. ambient temperatures

The ISpac isolators can be used over a wide temperature range. Depending on the isolator version and installation method different maximum ambient temperatures may result.

	Ventilation:	Without ventilation				
	Installation:	Single unit	DIN-rail		pac-C	Carrier
	Orientation:	any	vertical horizontal		vertical	horizontal
Channels	Type:					
	9170/11-11-1* 9170/11-12-1*		65 °C	65 °C	60 °C	65 °C
1	9170/11-14-1*	70 °C	70 °C	70 °C	65 °C	70 °C
	9170/11-11-21 9170/11-12-21		65 °C	70 °C		
	9170/21-*0-1* 9170/21-11-1* 9170/21-12-1*		55 °C	60 °C	50 °C	55 °C
2	9170/21-14-1*	70 °C	65 °C	65 °C	60 °C	65 °C
	9170/21-10-2* 9170/21-11-2* 9170/21-12-2*		55 °C	60 °C		
	Ventilation:			With ventilation	1	
	Installation:	Single unit	DIN	-rail	pac-Carrier	
	Orientation:	any	vertical	horizontal	vertical	horizontal
Channels	Type:					
	9170/11-11-1* 9170/11-12-1*		70 °C	70 °C	70 °C	70 °C
1	9170/11-14-1*	70 °C	70 °C	70 °C	70 °C	70 °C
	9170/11-11-2* 9170/11-12-2*		70 °C	70 °C		
	9170/21-*0-1* 9170/21-11-1* 9170/21-12-1*		65 °C	65 °C	60 °C	65 °C
2	9170/21-14-1*	70 °C	70 °C	70 °C	65 °C	65 °C
	9170/21-10-2* 9170/21-11-2* 9170/21-12-2*		65 °C	65 °C		

#### 5.2 Power dissipation

Data sheets are describing the maximum power dissipation in standard operation. In practice not all isolators are working with full load. Therefore engineering is done typically with an average power dissipation of 70 % ( $P_{70\%}$ ).

Туре	Channels	max. power dissipation	70 % power dissipation
9170/11-1*-1*	1	0,7 W	0,5 W
9170/21-**-1*	2	1,2 W	0,8 W
9170/11-14-1*	1	0,6 W	0,4 W
9170/21-14-1*	2	0,7 W	0,5 W

#### 5.3 Engineering of the power dissipation in cabinets

When electronic devices are integrated in cabinets free air movement is restricted and the temperature rises. To minimise the temperature rise it is important to optimise the power dissipation as well as the elimination of the produced heat inside a cabinet.

#### a) Natural Convection in closed cabinets

- Application: when the dissipated power is moderate and when the system operates in a dusty or harsh environment
- Calculation of the maximum allowed power dissipation:

#### $Pmax = \Delta t * S * K$

P<sub>max</sub> [W] max. allowed power dissipation in the cabinet

 $\Delta t$  [°C] max. allowed temperature rise

S [m²] free, heat emitting surface of the cabinet

K [(W/m<sup>2</sup>\*°C)] thermal emitting coefficient (K=5.5 for painted steel sheets)

The calculated value for  $P_{max}$  has to be smaller than the total average power dissipation (70 % of max. power dissipation) of the installed isolators:  $P_{max} < \sum P_{70\%}$ 

#### b) Natural convection in open cabinets

• Function: the heat is removed by cool air flowing through the devices

- Requirements:
  - inlet and outlet ports in the lower and upper ends of the cabinet
  - the air flow path must be kept free from obstacles.
- <u>Result</u>: Depending on the engineering the improvement can reach a two times higher power dissipation as with a)

#### c) Forced ventilation with heat exchanger in closed cabinets

- <u>Application</u>: when either the harsh environment or the high dissipated power do not allow natural convection
- <u>Function</u>: a heat exchanger with a fan pulls the air into the cabinet and pushes it into the heat exchanger plates that are cooled by the external ambient air moved by a second fan.
- <u>Result</u>: Depending on the engineering the improvement can reach a 5 or 6 times higher power dissipation as with a)

#### d) Forced ventilation in open cabinets

- <u>Function</u>: the filtered air is taken from the bottom cabinet openings by one or more fans, flows <u>through the devices</u>, and finally exits at the top of the cabinet.
- · Calculation of the required air flow:

#### $Q = (3.1 * P_{70\%}) / \Delta t$

Q [m³/h] required air flow

P<sub>70%</sub> [W] dissipated power (70 % of max. power dissipation)


 $\Delta t$  [°C] allowed temperature rise in the cabinet

#### e) Air conditioned cabinets

- Application: for hot climates it is possible to reach a cabinet temperature equal or even lower than the ambient temperature
- <u>Function</u>: a specific refrigerating system or the existing air conditioning system can be used for cabinet conditioning

## 6 Arrangement and fitting

#### 6.1 Dimensions



	Dimension X
Screw terminals	108 mm
Spring clamp terminals	128 mm
Insulation-cutting	131 mm

#### 6.2 Installation

The switching repeater is to be installed outside of hazardous areas. Type 9170/\*1-\*0-1\*; 9170/\*1-\*1-1\* and 9170/\*1-\*4-1\* switching repeaters are also approved for operation in Zone 2 and Zone 22 hazardous areas. For this purpose, the modules are to be built into an enclosure which meets the requirements of EN 60079-15 or EN 61241-1 (e.g. 8146 enclosure from R. STAHL Schaltgeräte GmbH).

#### 6.3 Mounting and dismounting

#### a) Detachable terminals

All devices are provided with detachable terminals. A screwdriver is needed to remove the terminals (as shown in the picture).




#### b) Mounting on DIN rails

Set the device on the DIN rail and tilt/snap onto the rail as depicted.

Do not tilt at an angle to either side when snapping onto the rail.

To dismount, use a screwdriver to gently pry up the lock on the mounting foot and then remove the module.



As depicted in the photo, set the device in position on the pac-Bus (already mounted on the DIN rail) and tilt/snap until it locks in.

Do not tilt at an angle to either side when snapping onto the pac-Bus.

<u>Note</u>: In order to prevent pole reversal during installation, the pac-Bus elements have been equipped with a keyed connection plug (see photo). The module is fitted with a matching slot.



Dismount as described below in b).

#### d) Mounting in the pac-Carrier


The black and green terminals must be removed before installation. Please remove additionally the cover for the second unused socket at single channel modules (apply a screwdriver at the lower edge). Set the ISpac modules in place as described in a) and b) and completely tilt/snap into the pac-Carrier.

Close the red latching lever using gentle pressure. The latching lever must engage completely.


To dismount, use a screwdriver to open the latching mechanism as shown in the picture. The module is nudged out of the slot and can be removed.



#### 7 Commissioning




)\* Versions 9170/11-11-13 and 9160/21-11-13 do not offer line fault signalization via relay contact.



9170/	/21-11-**	/11-11-**	/21-*0-** /21-*2-**	/11-12-**	/21-14-**	/11-14-**
Channel 2	\$\begin{array}{c} \cdot		\$ 06 05 04		⇒ 06 05	
Channel 1	\$\frac{03}{02}	06 05 04 03 02 01	O3 O2 O1	\$ 03 02 01	⇒ 02 01	⇒ C2 01

Special output circuits of types 9170/11-14-12 LFT, 9170/11-14-12-C1515 LFT, 9170/21-14-12 LFT and 9170/21-14-12-c1515 LFT:



Line faults – no matter if short circuit or line break - detected by the switching repeater in the intrinsically safe field circuit are causing the additional LFD contact in the output circuit to open. The additional resistors in the output circuit emulate a NAMUR signal. The types 9170/11-14-12-C1515 LFT und 9170/21-14-12-C1515 LFT may only be connected to Yokogawa ProSafe.

#### 7.2 Engineering

a) Mode of connection for line fault identification (volt-free contacts at the input)

Open circuit identification: 10 k $\Omega$  in parallel Short circuit identification: 1 k $\Omega$  in series

The loading has to carry out in direct proximity of the

10 κΩ


contact.

b) Mode of connection for inductive loading at the output:



Inductive loadings have to be connected with a free wheel diode.

We do not recommend to use a loading via varistor.



#### 7.3 Settings

	Line fault de	tection (LF)	Output inverted (INV)			
	deactivated *)	activated	OFF *)	ON		
Channel 1	OFF ON  LF1  1 INV1	OFF ON LF1 INV1	OFF ON  1 LF1 INV1	OFF ON  LF1  INV1		
Channel 2	2 LF2 INV2	2 LF2 INV2	2 LF2 INV2	2 LF2 INV2		

<sup>\*)</sup> Default factory setting

Changing settings via DIP switches during operation is also permitted in Zone 2 and on circuits carrying intrinsically-safe input signals.

## 8 Operation and operational states

		Output state for "line of action inverted" (see 7.3)				
Input	Input current	OFF	ON			
Line fault detection LF =	deactivated					
Proximity switch high impedance / Contact: open / open circuit	$I_E \leq 1.2 \text{ mA}$	Relay not energized / Electronic output deactivated	Relay energized / Electronic output activated			
Proximity switch low impedance / Contact: closed / short circuit	$I_E \ge 2.1 \text{ mA}$	Relay energized / Electronic output activated	Relay not energized / Electronic output deactivated			
Line fault detection LF = a	activated					
Open circuit	$I_E \le 0.050.35 mA$	Relay not energized / Electronic output deactivated	Relay not energized / Electronic output deactivated			
Proximity switch high impedance / Contact: open	I <sub>E</sub> = 0.351.2 mA	Relay not energized / Electronic output deactivated	Relay energized / Electronic output activated			
Proximity switch low impedance / Contact: closed	I <sub>E</sub> = 2.15 mA	Relay energized / Electronic output activated	Relay not energized / Electronic output deactivated			
Short circuit	$R_E \geq 100360~\Omega$	Relay not energized / Electronic output deactivated	Relay not energized / Electronic output deactivated			

Exceptions are the types 9170/11-14-12 LFT, 9170/11-14-12-C1515 LFT, 9170/21-14-12 LFT and 9170/21-14-12-c1515 LFT (see chapter 7.1)

## 9 Maintenance and repair

It is recommended that all repairs to our devices be carried out by R. STAHL. In exceptional cases, repair may be performed by approved third-parties.

The devices are maintenance-free.

#### Troubleshooting chart:

Error detection	Malfunction cause(s)	Corrective action
"PWR" LED does not lit	Power supply failure	Check power supply.
	Device fuse is defective	If device fuse is defective, send device in for repair.
	Polarity reversal	Connect the power acc. to operating guide
"LF" LED lights all the time	Switching element is not connected correctly – short circuit or disruption Switching element does not work in compliance with NAMUR	Please verify that the connection is established correctly. Please apply the mode of connection for volt-free contacts as described in 7.2.
LED "OUT" lights but the state of operation at the output does not change	The exchangeable terminals are mixed up.	Please connect the terminals to the predefined socket.
High switching frequencies are not transmitted	The electronic output is optimized for the application along with active I/O cards. In case of passive I/O cards the potential for the generation of High Level is missing.	The High Level can be generated if an resistor is connected externally to the supply voltage (e.g. +5V).

#### Self test

In order to check basic functions of the device, you may apply the following test steps. Please disconnect the exchangeable terminals first. (see 6.3)

- Connect the device to the power supply (via pac bus or directly via terminals 7 and 9)
- Deactivate the line fault detection my means of the DIP switches at the front of the device.
- Establish an electrical connection between terminal 10 and 11 (in case of dual channel devices additionally between terminal 14 and 15)
- The LED "OUT" (yellow) lights up. It indicates that the output has switched. If you
  disconnect the connection between the terminals the LED turns dark. The result
  of this test indicates that input signals are processed.
- Activate the line fault detection. The LED "LF" lights up no matter if the connection between the terminal is established or not.

If the procedure described above does not obtain the desired result, please contact your local R. STAHL sales and service representative. In order to quickly process your request, please provide us with the following information:

- Type and serial number
- · Purchase date
- Description of malfunction
- Application description (particularly the configuration of the input/output circuitry)

#### 10 Accessories and spare parts

Use only original spare parts from R. STAHL Schaltgeräte GmbH.

## EG-Konformitätserklärung / EC-Declaration of Conformity

#### EG-Konformitätserklärung EC-Declaration of Conformity

EC-Declaration of Conformity Déclaration de Conformité CE



Wir (we: nous)

R. STAHL Schaltgeräte GmbH, Am Bahnhof 30, 74638 Waldenburg, Germany 9170/ab-cd-ef a = 1, 2 b = 0 - 2 c = 1 - 3, 6 d = 0 - 4 e = 1, 2 f = 0 - 3

erklären in alleiniger Verantwortung, dass das Produkt hereby declare in our sole responsibility, that the product déclarons, sous notre seule responsabilité, que le produit Schaltverstärker Switching repeater Relais amplificateur

mit der EG-Baumusterprüfbescheinigung:

(under; EC-Type Examination Certificate: avec) Attestation d'examen CE de type:

**DMT 02 ATEX E 195 X** 

auf das sich diese Erklärung bezieht, mit den folgenden Normen oder normativen Dokumenten übereinstimmt

which is the subject of this declaration, is in conformity with the following standards or normative documents

auquel cette déclaration se rapporte, est conforme aux normes ou aux documents normatifs suivants

Bestimmungen der Richtlinie Nummer sowie Ausgabedatum der Norm terms of the directive Number and date of issue of the standard prescription de la directive Numéro ainsi que date d'émission de la norme 94/9/EG: ATEX-Richtlinie IEC 60079-0: 2007 94/9/EC: ATEX Directive EN 60079-11: 2007 94/9/CE: Directive ATEX EN 60079-15: 2005 EN 60079-26: 2007 EN 50303: 2000 EN 61241-0: 2006 EN 61241-11: 2006 2004/108/EG: EMV-Richtlinie 2004/108/EC: EMC Directive EN 61326-1: 2006 2004/108/CE: Directive CEM 2006/95/EG: Niederspannungsrichtlinie EN 50178: 1997 2006/95/EC: Low Voltage Directive EN 61010-1: 2001 2006/95/CE: Directive Basse Tension

Qualitätssicherung Produktion:

Production Quality Assessment: PTB 96 ATEX Q006-6

Assurance Qualité Production:

Kenn-Nr. der benannten Stelle / Notified Body number / N° de l'organisme de certification: 0102

Waldenburg, 24.06.2009

Ort und Datum
Place and date
Lieu et date

J.-P. Rückgauer // Leiter Entwicklung und Technik Director Design and Technology Directeur Développement et Technique Dr. S. Jung Leiter Qualitätsmanagement Director Quality Management Dept. Directeur Dept. Assurance de Qualité

#### Certification drawing - FM Type 9170/\*1

# Type 9170/\*1-\*\*-1\* (for 24 V DC) Hazardous area

(only at 9170/2)

Type 9170/\*1-\*\*-2\*

(for 120 / 230 V AC or with power relay)

The Switching Repeater Type 9170/\*1-\*d-1\* (d = 0, 1, 4) is an associated apparatus as well as a nonincendive apparatus for installation in non-hazardous. Class I, Division 2 or Zone 2 hazardous (Classified) Locations and provides intrinsically safe connections for one (or two) field devices located in Class I, II, III, Division 1, Group A-G or Class I, Zone 0 [AEx ia] Group IIC, hazardous locations according to NEC Article 504/505 as listed below.

The Switching Repeater Type 9170/\*1-\*\*-2\* and Type 9170/\*1-\*d-\*\* (d = 2, 3) is an associated apparatus located in a non-hazardous location and provides intrinsically safe connections for one (or two) field devices located in Class I, II, III, Division 1, Group A-G or Class I, Zone 0 [AEx ia] Group IIC, hazardous locations according to NEC Article 504/505 as listed

#### Switching Repeater Type 9170/a1-cd-ef

- a = numeral 1 or 2 for number of channels
- c = numeral 1, 2, 3, 4, 5 or 6 for input signals d = numeral 0, 1, 2, 3 or 4 for output stage
- e = numeral 1 or 2 for power supply
- f = numeral 0, 1, 2 or 3 for line fault detection

Entity parameters for wiring configurations are as follows:

				Lo	L <sub>o</sub>	C.	C <sub>o</sub>		
	V <sub>∞</sub>	I <sub>sc</sub> [mA]	Po [mW]	CL. I, Div.1, A,B / Zone 0, GP. IIC	CL. I, Div.1, C-G / Zone 0, GP. IIB	CL. I, Div.1,A,B / Zone 0, GP. IIC	CL. I, Div.1, C-G / Zone 0, GP. IIB	V <sub>max</sub>	I <sub>max</sub>
Type 9170/*1-c*-** (with c = 1, 3, 4, 5, 6)	9.6	10	24	350 mH	1000 mH	3.6 µF	26 µF	151	-
input circuits parallel	9.6	20	48	90 mH	340 mH	3.6 µF	26 µF	121	12
Type 9170/*1-2*-**	9.6	0.61	1.5	1000 mH	1000 mH	3.6 µF	26 µF	10-11	-
input circuits parallel	9.6	1.22	3.0	1000 mH	1000 mH	3.6 µF	26 µF	-	

#### Notes:

- Intrinsically safe apparatus may be switches, thermocouples, LEDs, RTDs or an FM Approved System or Entity device connected in accordance with the manufacturer's installation instructions.
- 2. For Entity concept use the appropriate parameters to ensure the following:  $C_o, C_a \ge C_i + C_{leads}$   $L_o, L_a \ge L_i + L_{leads}$  $V_t$  or  $V_{OC} \leq V_{max}$

It or Isc & Imax

- Electrical apparatus connected to an intrinsically safe system should not use or generate voltages > 250 V (U<sub>max</sub>).
- Installation should be in accordance with Article 504/505 of the National Electrical Code, ANSI/NFPA 70 and ANSI/ISA RP 12.06.01
- Use a general purpose enclosure meeting the requirements of ANSI/ISA S82.02.01 for use in non-hazardous or Class I, Division 2, hazardous (Classified) locations.
- Use an FM Approved Dust-ignition proof enclosure appropriate for environmental protection in Class II, Division 1, Groups E,F and G; and Class III, hazardous (Classified) locations.
- Each channel shall be installed within a separately shielded cable or a single cable with a separate shield for each channel.
- These modules are to be mounted on DIN rail, DIN rail with pac-Bus (type 9194) or pac-Carrier (type 9195). The field wiring in any case is connected to the IS pac device terminals
- 9. Ambient temperature: -20 °C ... +70 °C (any mounting position)

-[				2009	Dato	Name		Certification drawing	Scale
- 1				Drawn by	08.05.	Einsiedler	2000	0	none
				Checked		Kaiser	Switching	Repeater	Sheet
4830 503				1 '			Type 917	0/*1-**-**	1 of 1
		k				STAHL		91 706 02 31 1	Agency FM
F 48	Index	Date	Name	7			Rep. f.	Rep. t.	A4

Verveifätigung dieses Dokuments, Verwertung und Mittellung verboten, soweit nicht ausdrücklich gestattet. Zuwider-chten zu Schadenessatz, Alle Rechte Tür den Fäll der Palent-oder Geschmuckennusterenfrag vorbehalten.

uslization of this document as well as the communication it appressed authorization is prohibited. Offenders will of damages. All rights reserved in the event of the gran mamental design modulation.

Hazardous area: Class I, II, III; Group A-G or Class I; Zone 0; Group IIC/IIB Hazardous Locations Switching Repeater Type 9170/a1-cd-ef

- a = numeral 1 or 2 for number of channels d = numeral 0, 1, 2, 3 or 4 for output stage f = numeral 0, 1, 2 or 3 for line fault detection
- c = numeral 1, 2, 3, 4, 5 or 6 for input signals e = numeral 1 or 2 for power supply

i ne maximum output p	arameters for	this device a	re:					
	V <sub>oc</sub> (U <sub>e</sub> )	lsc (l <sub>o</sub> )	P <sub>o</sub>	L <sub>a</sub> (L <sub>o</sub> ) A. B / IIC	L <sub>s</sub> (L <sub>s</sub> ) C-G / IIB	C <sub>s</sub> (C <sub>o</sub> ) A. B / IIC	C <sub>a</sub> (C <sub>b</sub> ) C-G / IIB	l
Type 9170/*1-c*-** (with c = 1,3,4,5 or 6)	(00)	(10)		7, 57110	0-07110	A, B / IIC	0-07110	ĺ
single channel input circuits parallel	9.6 V 9.6 V	10 mA 20 mA	24 mW 48 mW	350 mH 90 mH	1000 mH 340 mH	3.6 µF 3.6 µF	26 μF 26 μF	
Type 9170/*1-2*-** single channel	9.6 V	0.61 mA	1.5 mW	1000 mH	1000 mH	3.6 µF	26 µF	

Nominal ratings of the output circuits are:

	U <sub>n</sub>	l <sub>a</sub>	P <sub>n</sub>
Type 9170/2*-*0-** Type 9170/*1-*1-**	125 V AC or DC	1 A	25 W 50 VA
Type 9170/"1-"2-" Type 9170/11-"3-"	250 V AC or DC	2 A DC 4 A AC	50 W 1000 VA
Type 9170/*1-*4-**	35 V DC	50 mA	1.75 W

nt for models type 0170/\*1\_\*\*\_\*\*

maximum su	ippiy current i								
		at 18	V DC source,	at 96 V AC, terminals L and N					
Type	11-*1-11	11-*4-11	11-*3-11	21-30-10	21-*0-11	21-*4-11	21-"0-21	21-*0-23	11-*1-21
	11-*2-11	11-*4-12			21-*1-11	21-*4-12	21-*1-21	21-*1-23	11-*2-21
					21-*2-11		21-*2-21	21-*2-23	
I [mA]	44	31	57	45	75	50	19,5	19,5	11,3

- Intrinsically safe apparatus may be switches, thermocouples, LEDs, RTDs or an FM Approved System or Entity device connected in accordance with the manufacturer's installation instructions.
- 2. For Entity concept use the appropriate parameters to ensure the following:  $C_0$ ,  $C_k \ge C_i + C_{leads}$   $L_0$ ,  $L_k \ge L_i + L_{leads}$  $\dot{V_t}$  or  $\dot{V_{OC}} \leq \dot{V_{max}}$ 
  - $I_t$  or  $I_{SO} \le I_{max}$
- 3. Electrical apparatus connected to an intrinsically safe system should not use or generate voltages > 250 V (Umax).
- 4. Suitable separation must be maintained between IS wiring and all other non-IS wiring.
- 5. Installation should be in accordance with Canadian Electrical Code. Part I.
- 6. Use a general purpose enclosure appropriate for environmental protection.
- These modules are to be mounted on DIN rail, DIN rail with pac-Bus (type 9194) or pac-Carrier (type 9195).
   The field wiring in any case is connected to the IS pac device terminals.
- 8. Ambient temperature: -20 °C ... +70 °C (any mounting position)

WARNING: Explosion hazard - Do not disconnect equipment, replace fuses, or unplug modules from the pac-Carrier type 9195 or pac-Bus type 9194 unless power has been switched off or the area is known to be non-hazardous.

				2009	Date	Матю	Certification	on drawing	Scale	Т
				Drawn by	24.09.	Reistle		ar drawing	none	
				Checked		Bagusch	Switching Repeater		Sheef	_
							Type 9170/*1-**-**	0/*1-**-**		
۱				l		(-)			Agency	_
б				l		[STAHL]	91 706	706 02 31 2		
3				ı			01700	02 01 2	CSA	
	Index	Date	Mame				Rep. f.	Rep. L	,	Α4



R. STAHL Schaltgeräte GmbH Am Bahnhof 30 74638 Waldenburg (Württ.) – Germany

www.stahl.de